

POOLDECK REPAIR

E-Z INSTRUCTIONS FOR A "KOOLDECK® TYPE HIGH-LOW TEXTURE:

- 1. Chip out any loose or flaking pooldeck.
- 2. Scrub area with water and brush using muriatic acid or laundry soap if needed.
- **3.** Immediately rinse the area thoroughly and dab with sponge until damp only.
- **4.** Add LIQUID CEMENT BONDER to DRY CEMENT MIX (use fractions = ½ of the dry mix to ½ of the liquid cement bonder, etc.). and add water and mix until you get the consistency of "mashed potatoes".
- **5A.** FOR CRACK REPAIR: Rub E-Z PATCH® 2 into crack assuring deep penetration into crack (add more water to mix if needed). Remove excess immediately with a moist sponge. Rinse sponge often. Allow repair to dry, and then remove any residue with a dry cloth.
- **5B.** FOR SMALL AREAS: Trowel about ¼" thick of E-Z PATCH® 2 onto the area, and then use your finger tips to "tap" E-Z PATCH® 2 all over to produce the "peaks" desired. If too wet to "peak", wait or use a hair drier until it stiffens enough to retain "peaks".
- **5C. FOR LARGER AREAS:** Add approx. 1 oz. of additional water per 1 lb. of E-Z PATCH® 2 and remix. Apply with a cooldeck dash brush leaving "peaks".
- **6.** Remove excess from edges immediately with a moist sponge.
- **7.** Allow the repair to dry (or use a hair drier) until the surface dulls, stiffens and doesn't stick to your <u>clean</u> moist trowel. Trowel the tops of the "peaks", starting with a <u>light</u> touch, increasing pressure a little at a time until you achieve the finished pattern desired. <u>Keep your trowel moist and clean!</u> If the repair is allowed to dry too hard to trowel, just mist or sprinkle the repair with water and trowel it again. Do not allow foot traffic for at least 24 hours and furniture for 3 days.

E-Z PATCH® 2 color will lighten when it dries but will darken somewhat as it cures. It takes 28 days for cement to cure.

To make a Custom Color with any of our cement type repair supplies, use any cement dye.

View our instructional repair video showing how to do this repair at www.e-zpatch.com

E-Z ANSWERS to some Frequently Asked Questions

- Liquid Bonder is inside the jar
- Product will cure faster in hotter weather, slower in cooler weather
- Product is best stored between 40 degrees F and 90 degrees F

| RUBBER GLOVES IS RECOMMEND | DED. KEEP OUT OF THE REACH OF CHILDREN | |
|----------------------------|---|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |