


# LOW PROFILE LIFEGUARD STANDS

## **ASSEMBLY INSTRUCTIONS**



(503) 266-2231 • Fax (503) 266-4334

#### www.srsmith.com


©S.R. SMITH, LLC 2004


#### INTRODUCTION

The Low Profile Lifeguard Stand is designed for use on competitive or municipal pools. Proper placement, use, and maintenance are essential for proper operation and to reduce the risk of accident or injury.

#### \*\*IMPORTANT\*\*

Check entire box and inside all packing materials for parts. Before beginning assembly, read the instructions and identify parts using the figures and parts listed in this document. It is critical that all parts be carefully inspected by the installer prior to installation to ensure that no damage occurred in transit and that a damaged part is not used. Proper installation cannot be overstressed, as an improper installation voids S.R. Smith's warranty and may affect the safety of the user.






### LOW PROFILE LIFEGUARD STAND PARTS LIST

ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1		LPLS-330 FRAME, LEFT
1	1		LPLS-342 FRAME, LEFT
2	1	20-303B	LPLS-330 FRAME, RIGHT
2	1	20-304B	LPLS-342 FRAME, RIGHT
3	1	20-301	LPLS-330/342 FRAME, REAR
4	1	20-303C	LPLS-330 FOOTBOARD SUPPORT, REAR
4	1	20-304C	LPLS-342 FOOTBOARD SUPPORT, REAR
5	1	20-302	LPLS-330/342 FOOTBOARD SUPPORT, FRONT
6	1	8-710	LPLS-330/342 FOOTBOARD
7	2	8-510	GASKET, 7-1/2'' X 7-1/2''
8	1	13-109	SWIVEL STAND W/ UMBRELLA HOLDER
9	1	20-202	SWIVEL STAND MOUNTING PLATE
10	5	BRB-100EX	BLUE BUMPER
11	1	2407030	SWIVEL, LIFEGUARD CHAIR
12	3	5-195	3/8-16 X 2-1/4" GUSSET HEAD BOLT, SS
13	7	5-151	LOCK WASHER, 3/8'', SPLIT, SS
14	3	5-156	3/8-16 ACORN NUT, 316 SS
15	4	2300300	CARRIAGE BOLT, 3/8" UNC X 4" LONG, SS
16	16	05-14-114	FLAT WASHER, 1/2", SS
17	6	5-139	3/8" UNC, HEX NUT, SS
18	4	5-124	BOLT, 1/2" UNC X 3.0 LG
19	4	05-14-115	LOCK WASHER, 1/2'', SS
20	4	05-14-116	1/2" HEX NUT S/S
21	4	05-618	NUT CAP, 1/2", WHITE PLASTIC
22	4	2024189	SCREW, 1/4" X 3/4" LG, PAN HD, SLOTTED, SS
23	8	5-149	LOCK WASHER, 1/4'', SPLIT, SS
24	8	5-137	HEX NUT, 1/4" UNC, SS
25	1	8-609	LIFEGUARD SEAT
26	2	5-117	1/2" X 5-1/2" BOLT, S/S
27	2	8-862	PLS 6" WHEEL
28	2	05-14-116	1/2"-13 HEX NUT, S/S
29	1	LTDF-103	20" ELITE TREAD, SS, NO HARDWARE
30	2	5-170	3/8"-16 X 2-1/2" CRADLE HEAD BOLT

#### ASSEMBLY INSTRUCTIONS

Unless specified otherwise, assembly instructions apply to both LPLS-330 and LPLS-342 models.

1. Begin by placing the LPLS-330/342 Footboard, (item 6) onto the LPLS-330/342 Rear Frame (item 4) being careful to orient as shown in FIGURE 3.



 Place Blue Bumpers (item 10) five (5) places in the frame tube ends as shown in FIGURE 4. Join LPLS-330/342 Right Frame (item 2) with LPLS-330/342 Front Footboard Support (item 5) and the LPLS-330/342 Rear Frame (item 3).

> Place the joined LPLS-330/342 Right Frame, LPLS-330/342 Front Footboard Support and the LPLS-330/342 Rear Frame into the LPLS-330/342 Rear Footboard Support (item 4). Place LPLS-330/342 Left Frame (item 1) over the ends of the Front and Rear Footboard Support frames.

> Place 3/8" Cradle Head Bolts (item 12) through LPLS-330/342 Rear Frame and LPLS-330/342 Rear Footboard Support two (2) places. Place 3/8" Cradle Head Bolt (item 12) through LPLS-





FIGURE 4

**330/342 Right Frame (item 2)** and LPLS-330/342 Rear Frame (item 3) one (1) place. Place 3/8" Lock Washer (item 13) and 3/8" Acorn Nut (item 14) over Cradle Head Bolts three (3) places as shown in FIGURE 4.


Place <sup>1</sup>/<sub>2</sub>" Flat Washer (item 16) over 3/8" Carriage Bolt (item 15) four (4) places. Place Carriage Bolt and Flat Washer through Footboard and Frame members four (4) places. Place 3/8" Lock Washer (item 13) and 3/8" Hex Nut (item 17) onto Carriage Bolts four (4) places. Do not tighten at this time.

(LPLS-342 ONLY) Place 20" Elite Tread (item 29) between Rear Footboard Support and Left LPLS-330/342 Frame and align holes of Elite Tread with holes in frames. Place 3/8" Cradle Head Bolts (item 30) through LPLS-330/342 Left Frame and LPLS-330/342 Rear Footboard Support two (2) places as shown in FIGURE 5. Place 3/8" Hex Nut (item 17) over Cradle Head Bolts.




#### FIGURE 5

- Place 1/2" X 5-1/2" Bolt (item 26) through LPLS-330/342 Left Frame (item 1) and LPLS-330/342 Right Frame (item 2) two (2) places. Place ½" Flat Washer (item 16), PLS 6" Wheel (item 27), ½" Flat Washer (item 16), and ½"-13 Hex Nut (item 28) over bolts and tighten as shown in FIGURE 5.
- Place Swivel (item 11) onto Swivel Stand W/ Umbrella Holder (item 8) orienting as shown in FIGURE 6. Place Screw (item 22) through Swivel and Swivel Stand (4 places). Place ¼" Lock Washer (item 23) and ¼" Hex Nut (item 24) onto Screw and tighten (4 places).
- Place Lifeguard Chair (item 25) onto Swivel. Attach ¼" Lock Washer (item 23) and ¼" Hex Nut (item 24) onto Lifeguard Chair studs and tighten (4 places) as shown in FIGURE 6.



7. Place ½" Flat Washer (item 16), Swivel Stand Mounting Plate (item 9) and Gasket (item 7) over ½" X 3" Long Bolt (item 18) four (4) places. Place Bolts, Washers, Swivel Stand Mounting Plate and Gasket through holes in underside of Footboard and hold parts in place. Place Gasket (item 7) and Swivel Stand/ Lifeguard Chair Assembly onto exposed bolts on top of footboard. Place ½" Flat Washer (item 16), ½" Lock Washer (item 19) and ½" Hex Nut (item 20) over ½" X 3" Long Bolt and tighten Hex Nuts. Place ½" Plastic Nut Cap (item 21) over Hex Nuts four (4) places. See FIGURE 7.



FRAMES REMOVED FOR CLARITY

FIGURE 7

8. Tighten all fasteners being careful to compress all lock washers and no further. Excessive tightening of fasteners can result in damage to tubing and related parts voiding warranty and creating an unsafe structure.

