

How to Replace Internal CAM Assembly

Step 1. Disassemble the pole. Place the CAM Assembly with the pole into a vice. Do not place the pole portion in the vice, just the CAM part (as shown in video).

Step 2. Take a hacksaw or metal cutting tool and come back about 2 inches from the CAM plug and cut the pole off. Then take a pocket knife or file and remove the inside and outside burrs.

Step 3. Take the NIC part or the 505 and insert it into the pole. You will then take the pole and tap it on a hard surface (concrete floor or deck) until the NIC or 505 shoulder is even with the pole or within 1/16 inch.

You've now installed an inside CAM assembly for a Skimplite pole.

Skimplite has many helpful videos which we have posted on our website (poolweb.com). You can also find them on the Skimplite site or on Youtube.

