

Buoy Label	Number
Danger	46104WV0003324E
Danger Keep Out	46104WV1003324E
Danger Rocks	46104WV2003324E
Danger Stump	46104WV3003324E
Hazard Area	46104WV4003324E
Idle Speed	46104WV5003324E
Keep Out	46104WV6003324E
No Boats	46104WV7003324E
No Fishing	46104WV8003324E
No Swimming	46104WV9003324E
No Wake	46104WV1103324E
Shallow Area	46104WV1203324E
Ski Area	46104WV1303324E
Slow 5 MPH	46104WV1403324E
Slow No Wake	46104WV1503324E
Swim Area	46104WV1603324E