



JANDY CONTROLLER COMPATIBLE MULTI-COLOR LED OPERATING MANUAL

These instructions are applicable to Blue Square Spectrum™ 360 LED Multi-Color Lights programmed to be compatible with Jandy® Controllers. Our LED Pool Lights (J-Series) can be operated from either a wall switch or connected to a Jandy® Controller.

When connected to the Jandy® Controller, the fixed colors and color-shows can be easily selected using the controller.

When connected to a Wall Switch, manually switching on and off a specific number of times activates the fixed color modes and color-shows.

Turn the light on. The first time the light is turned on, the color sequence begins with Alpine White. To change the color, turn the light off and on within three (3) seconds. Continue turning off and on until the desired color mode is reached. See below table for the color mode sequence. When the light is turned off for more than seven (7) seconds, it will remain in the color set that is currently active. When the light is turned back on, the light will be on the same color set.

PROGRAMMING MODES

Cycles	Mode
1	Alpine White
2	Sky Blue
3	Cobalt Blue
4	Caribbean Blue
5	Spring Green
6	Emerald Green
7	Emerald Rose
8	Magenta
9	Violet
10	Slow Color Splash
11	Fast Color Splash
12	America the Beautiful
13	Fat Tuesday
14	Disco Tech

Number of times to cycle power (1-14)

Resetting to the Beginning of the Color Sequence:

- Turn the light **OFF**
- Wait four (4) to six (6) seconds
- Then turn **ON**
- Light will return to the beginning of the color cycle (Alpine White)



For supply connection, use only an isolating low voltage power supply with ungrounded output, evaluated for swimming pool use.



Toll Free: 800.277.4150 | BlueSquaremfg.com

WARNING
NEVER STARE DIRECTLY AT LED POOL LIGHTS.
 PROLONGED DIRECT EXPOSURE CAN CAUSE EYE DAMAGE.