

MODEL P1251P



**PORTABLE TWO CIRCUIT OUTDOOR
TIMER WITH GROUND FAULT PROTECTION.**

TOTAL LOAD NOT TO EXCEED: 15A. RESISTIVE, 1800W (15A.)

TUNGSTEN, 1 HP (15 FLA, 90 LRA) - 120 VOLT 60 HZ.

TIMED & PHOTO CONTROL LOAD: 900W 120 VOLT 60 HZ.

Suitable for Outdoor Use, Pool/Spa Equipment Control

IMPORTANT

This portable timer is designed for **CONTROLLING** the connected equipment only. Unplug timer before servicing the unit or the equipment it controls. ***THIS DEVICE IS NOT TO BE USED AS A POWER DISCONNECT!*** For maximum protection against electrical shock hazard, perform test procedure on GFCI at least once a month. If used to control pool/spa equipment install at least 5 feet from inside edge of pool/spa.

GFCI TEST PROCEDURE

The GFCI should be checked every month to make sure it is operating properly. It is recommended that a permanent record of the monthly safety check is maintained.

1. Push **TEST** button. **RESET** button should pop out from inner surface. This should result in power being **OFF** at the outlets. Verify by plugging test lamp into **TIMED** outlet. Be sure the timer is in the **ON** position.
2. If the GFCI tests okay, restore power by pushing the **RESET** button back in. **THE RESET BUTTON MUST BE PUSHED FIRMLY AND FULLY INTO PLACE UNTIL IT LOCKS AND REMAINS DEPRESSED AFTER PRESSURE HAS BEEN REMOVED.**

DANGER IF **RESET** BUTTON DOES **NOT** POP OUT, IF **TEST LAMP REMAINS LIT** WHEN **RESET** BUTTON DOES POP OUT, OR IF **GFCI FAILS TO RESET PROPERLY, DO NOT USE TIMER! CONTACT A QUALIFIED SERVICE TECHNICIAN!**


TIMER - OPERATING INSTRUCTIONS

TIMED OUTLET: is controlled **ONLY** by the timer.

TIMED & PHOTO CONTROLLED OUTLET: need both Photo Control and Timer to be activated for the load to turn on. The load will turn off when either the Photo Control or Timer is deactivated.

1. Insert **ON (GREEN)** and **OFF (RED)** trippers into dial at desired **ON** and **OFF** times.
2. Turn dial clockwise and align arrow with **Time-of-Day (AM or PM)** in window.
3. Plug Pump into **TIMED** outlet.
4. Plug Light into **TIMED & PHOTO CONTROL** outlet.

FOR TEMPORARY MANUAL OPERATION

Rotate **MANUAL** knob counter-clockwise  to desired **ON** or **OFF** position. Timer will follow next automatic operation.

INTERMATIC INCORPORATED

SPRING GROVE, ILLINOIS 60081-9698

PRODUCT OF MEXICO