Swivel Installation

- 8. Place Swivel (item 25) onto Swivel Stand W/
 Umbrella Holder (item 5) orienting as shown in
 FIGURE 6. Place Screw (item 26) through Swivel
 and Swivel Stand (4 places) as shown in FIGURE
 6. Place ¼" Lock Washer (item 27) and ¼" Hex
 Nut (item 28) onto Screw and tighten (4 places).
- Place Lifeguard Chair (item 30) onto Swivel.
 Attach ¼" Lock Washer (item 27) and ¼" Hex
 Nut (item 28) onto Lifeguard Chair studs and
 tighten (4 places) as shown in FIGURE 6.

