

### 3. ASSEMBLING THE POOL CLEANER


This section describes how to assemble your pool cleaner.

#### To assemble the Dolphin WAVE 300 XL Pool Cleaner:

1. Attach the Caddy handle to the Caddy base and fasten with the four screws and four nuts provided.
2. Attach the cable roller in its designated place, and fasten with two screws.



3. Connect the MMI communications cable to the power supply unit.
4. Connect the connection cable between the power supply and the cable roller.



Roller Inner Connection :3 Figure


## 4. WORKING WITH THE MMI CONSOLE

This chapter describes how to work with the MMI console and includes the following sections:

- MMI Console Overview, page 6
- MMI Alerts, page 7
- MMI Functions, page 7
- WAVE 300 XL Parameters, page 7
- Choosing Additional Pool Profiles, page 9

### 4.1 MMI Console Overview

The interactive MMI control console provides easy access to the robot's settings, functionality, and LED indicators.



MMI Console :4 Figure

- In this user manual, the term **Press Start** means to simultaneously press both green buttons on the MMI console (marked 2 and 3 in the Figure 4).
- The MMI is equipped with a screensaver that is displayed after 5 minutes of idle time. Press the **POOL** and **HOME** buttons (marked 5 and 6 in Figure 4) to exit the screensaver mode.
- Some options in the MMI (pool profile setup) menus are blocked with a code to prevent changing the setting accidentally. The code sequence for unblocking these options is: 3, 2, and 1 (Figure 4).