

Before testing read the **SET UP** section in the manual for instructions on setting up the WaterLink Spin meter and software.

TESTING

1. **Select** customer record from software.
2. Remove **disk** from package.
3. **Fill** syringe with pool or spa sample water.
4. **Fill** disk with pool or spa sample water per instructions on page 9 of manual.
5. **Insert** disk into meter.
6. **Cover** disk with black disk cover.
7. **Close** lid.
8. Click **RUN TEST** on computer.

NOTE: Samples suspected of having high levels of chlorine, above 15 ppm, should be pretested with a Wide Range pH/ Total Chlorine Test Strip (2987). Samples with high chlorine concentrations will bleach out the chlorine reagent in the disk and cause false low results.

DOS & DON'TS


- Always use black disk cover.
- Empty syringe of old sample before filling with next sample.
- Do not touch top or bottom of disk. Handle disk on edge.
- Do not fill disk while in the meter. Fill disk on clean, dry surface.

Go to www.lamotte.com/spin for:


- Instructional videos • Testing Tips
- Software Updates • Registering your meter

FILL THE DISK


1. Fill the disk using slow, even pressure. The sample water will fill the chambers between the baffles in a counter-clockwise order. Each chamber will fill from the bottom to the top. Sample water should be added until the sample water in the fourth chamber fills to the top of the chamber to the embossed fill line.



2. Do not over fill the disk. If the disk is overfilled, sample water will flow out of the over flow hole in the center of the disk. The disk is not leaking. Dry the disk and run the test.



3. Do not under fill the disk. If the disk is underfilled, the reagent chambers will not fill entirely and results will be inaccurate.



4. Wet disks should be dried thoroughly with a lint-free wipe. The disk should be handled only by the edges.

